



Lenovo Thinkpad x230 Battery Replacement

This guide will go through the steps necessary to remove the battery of a Lenovo Thinkpad x230.


Written By: Johannes



Step 1 — Preparations



- Turn off the computer.
- Disconnect the charging cable from the computer.

 Failure to unplug the cable could result in electric shock.

Step 2 — Locate the battery



- Flip the computer upside down.
- The red rectangle shows the location of the battery.

Step 3 — Unlock the left switch



- Locate the two switches that lock the battery. Push the left-hand switch outward into the "unlocked" position.

Step 4 — Remove the battery



- Now push and hold the right clip to the right while using your other hand to gently slide the battery away from the computer.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 11:21:21 PM.